
57007

Dual LED Slide Dimmer 2-Single Pole



SPECIFICATIONS

| Voltage | 120VAC, 60Hz |
|-----------------------|---------------|
| Incandescent/ Halogen | H00W Per Load |
| Dimmable LED and CFL | 200W Per Load |
| Operating Temperature | 32°F-104°F |

DESCRIPTION/ FEATURES

The dual slide LED dimmer switch provides precise control over the brightness of your LED lighting fixtures. Featuring two slide controls, it allows you to independently adjust the brightness of two separate light sources, offering customizable illumination to suit any mood or occasion. Designed for compatibility with LED bulbs, this switch ensures smooth dimming performance without flickering or buzzing, enhancing both ambiance and energy efficiency in your home or workspace.

- · Controls two lights up to 200-Watt each dimmer.
- Slide up to on/brighten and down to dim/off
- · Designed for single pole use.

WARNING

Turn off the power at the circuit breaker before installing the dimmer.


Please read and understand these instructions before proceeding with the installation. This device is designed for installation in accordance with the National Electric Code and local regulations. We recommend that a qualified electrician performs the installation. Ensure that the circuit breaker or fuse(s) are turned off and power is disconnected before wiring the device.

CAUTION - To reduce the risk of overheating and possible damage to other equipment, Do Not Install to control a receptacle, motor-operated appliance, fluorescent lighting fixture or a transformer supplied appliance.

- Risk of Electric Shock - More than one disconnect switch may be required to de-energize the device before servicing


WIRING DIRECTIONS

- 1. Insert the HOT wire to the dimmer's HOT terminal.
- 2. Insert the LOAD #1 wire to the dimmer's Load #1 terminal.
- 3. Insert the LOAD #2 wire to the dimmer's Load #2 terminal.
- 4. Insert the GROUND wire to the dimmer's GROUND terminal.



2

OPERATING INSTRUCTIONS



The dimming sliders has an off position when you move the slider all the way down. There will be a noticeable click when you slide to turn off.

WARRANTY INFORMATION

This device is warranted to be free of material and workmanship defects for 2 years from the date of purchase. Original receipt or proof of purchase from an authorized retailer must be presented upon warranty claim. ALL claims must be verified and approved by Enerlites, Inc. Warranties from other Enerlites products may vary. This warranty is nontransferable and does not cover normal wear and tear or any malfunction, failure, or defect resulting from misuse, abuse, neglect, alteration, modification, or improper installation. To the fullest extent permitted by the applicable state law, Enerlites shall not be liable to the purchaser or end user customer of Enerlites products for direct, indirect, incidental, or consequential damages even if Enerlites has been advised of the possibility of such damages. Enerlites' total liability under this or any other warranty, express or implied, is limited to repair, replacement or refund. Repair, replacement or refund are the sole and exclusive remedies for breach of warranty or any other legal theory.

3



© 2024 Enerlites Inc. CA, U.S.A. WWW.ENERLITES.COM 0203240239 REV 20232103